

## 1 General Description

The 15S Battery Cell Monitor & Balancer is a precision device that ensures multi-cell batteries are maintained in an optimal state, improving system reliability and prolonging battery life.



Figure 1 – 15S Battery Cell Monitor & Balancer

The 15S Battery Cell Monitor & Balancer does exactly as its name suggests: it monitors cells within a battery, and it balances those cells if and when they require it. Comprehensive data detailing the battery's internal state is sent via the CAN interface.

## 3 Usage

The Battery Balancer is intended to be connected to a battery, installed into a UAV and interfaced to the vehicle's CAN bus. A pair of indicator lights on the front panel give a "go / no go" indication of the battery's state of balance and state of charge. More detailed battery information is available via the CAN bus.

Use of the battery balancer confers a number of operational advantages:

- Batteries do not need to be removed periodically to check for balance.
- Battery status is available instantly, either directly from the front-panel LEDs, or remotely from the telemetry data sent on the CAN bus.
- Batteries are maintained in a state of balance, improving flight-readiness.

## 2 Features

- Transforms a "dumb" battery into a smart (self-balancing) battery.
- Supports multiple battery chemistries – LiPo, LiS and LiFe.
- Supports 9 to 15S batteries.
- Bidirectional 80 Amp current sensor.
- CAN interface provides control and monitoring of voltages, currents, temperatures.
- Battery temperature monitoring with up to 3 external sensors.
- User-friendly configuration software.
- Rich variety of balancing control options.
- Seamless integration with 1700W GCU.
- Weight: TBA
- PCB dimensions: 62 x 72mm

This page intentionally left blank.

## 4 Contents

1	General Description .....	1
2	Features .....	1
3	Usage.....	1
4	Contents.....	3
5	Quick Start Guide .....	4
6	Visual indicators .....	4
6.1	Balance LED .....	4
6.2	Charge LED .....	4
7	Connectors.....	5
7.1	Micro-USB connector .....	5
7.2	X1 – Battery balance connector.....	5
7.3	X2 – Internal current sense connector .....	5
7.4	X3 – Interface connector.....	6
7.4.1	CAN interface .....	6
7.4.2	Analog voltage.....	6
7.4.3	Master shutdown.....	6
7.4.4	External temperature sensors.....	7
7.4.5	External current sensor.....	7
8	Configuration Software .....	8
8.1	Configure tab.....	8
8.1.1	Number of cells.....	8
8.1.2	Current sensor.....	8
8.1.3	Wiring diagrams.....	8
8.1.4	Balancing control .....	9
8.1.5	Cell voltage limits.....	9
8.1.6	CAN interface .....	9
8.1.7	GCU integration .....	10
8.1.8	Visual indicators.....	10
8.2	Voltages tab .....	11
8.3	Current and Temperature tab .....	11
9	Specifications .....	12
9.1	Absolute Maximum Ratings.....	12
9.2	Recommended Operating Conditions.....	12
9.3	Electrical Specifications.....	12
10	Document version history.....	13
10.1	0.9 -> 1.0 .....	13
10.2	1.0 -> 2.0 .....	13
11	Reference data.....	14
11.1	Typical Lithium polymer characteristics at 23 °C .....	14
12	Wiring diagrams.....	15

## 5 Quick Start Guide

- Download the configuration utility from [www.millswoodeng.com.au/resources.html](http://www.millswoodeng.com.au/resources.html) and run it.
- Connect the balancer to your PC with a micro-USB cable.
- Click on the "Connect" menu item to establish a connection with the balancer.
- Click on the "Device" menu and check that reading the balancer's configuration settings works.
- Disconnect the balancer from your PC.
- Using the wiring diagram (given in section 12) corresponding to the number of cells in the battery, bridge the appropriate solder bridges on the balancer with a blob of solder.
- Using the same wiring diagram, wire up the cell balance connections between balancer and battery. Check your solder bridges and balance connections carefully before connecting the battery – a mistake here may damage the balancer.
- Reconnect the balancer to your PC.
- Click on the "Voltages" tab and check that cell voltages are being measured correctly.
- Click on the "Current and Temperature" tab and check that these are also being measured correctly.
- If desired, adjust the configuration settings and write these to the balancer.
- If desired, save your settings to a file.

## 6 Visual indicators

There are 2 LED indicators on the front panel, one for balance and one for charge. The LED colours have the following meanings:

### 6.1 Balance LED




 GREEN	The battery is balanced.
 RED	The battery is not balanced.
 OFF	No battery connected (or the Battery Balancer is sleeping).

Table 1 – Balance LED states

The balancing LED flashes when balancing is occurring.

### 6.2 Charge LED





 GREEN	The battery is fully charged.
 RED & GREEN	The battery is fully charged, but one (or more) cells are over or under voltage.
 RED	The battery is not fully charged.
 OFF	No battery connected (or the Battery Balancer is sleeping).

Table 2 – Charge LED states

The charge LED is only valid when the battery current is zero (i.e. not being charged and not under load).

The thresholds for both the charge and balance LEDs are user-configurable.

## 7 Connectors

### 7.1 Micro-USB connector

Used to connect the Battery Balancer to a PC. This connection is only required when configuring the Battery Balancer, although it may also be useful for displaying a battery's cell voltages, currents and temperatures in real-time.

### 7.2 X1 – Battery balance connector

X1 connects to the battery's cell balance connections. The PCB-mounted connector is a Harwin M80-5401642. Mating connectors include Harwin M80-4611605, M80-4611642, M80-4811605 and M80-4811642. These are crimp connectors suitable for AWG24 to AWG28 wire. Pin numberings are shown below.




Figure 2 – Harwin M80-5401642 pin numbering

Wiring from this connector to the cell balance connection points is dependent on the battery's cell count. See section 12, Wiring diagrams.

### 7.3 X2 – Internal current sense connector

The internal current sensor operates independently from the rest of the battery balancer, and use of the internal current sensor is entirely optional. Because of the wide common-mode range of the current sensor, it may be wired in series with either the positive or negative battery lines.

The PCB-mounted connector is a Harwin M80-5000000M5-04-PM3-00-000. The mating connector is a Harwin M80-4000000F1-04-PF5-00-000. This is a solder connector suitable for AWG10 wire. Pin numberings are shown below.




Figure 3 – Harwin M80-5000000M5-04-PM3-00-000 pin numbering

Pins on this connector are only rated for 40 Amps, and so pairs of pins wired in parallel are used for input and output.

Pin	Name	Type	Description
A, B	I <sub>sense in</sub>	Input	Pins A and B are connected together internally
C, D	I <sub>sense out</sub>	Output	Pins C and D are connected together internally

Table 3 – Internal current sensor pin allocations

If wired in series with the positive battery line, pins A and B should be connected to the battery's positive terminal, and the load connected to pins C and D. Charging current is defined to be positive.

### 7.4 X3 – Interface connector

This connector is the same type as the balance connector (X1), a Harwin M80-5401642.

**Exercise caution when plugging in the interface connector – plugging a live balance connector in by mistake will destroy the battery balancer.**




Figure 4 – Harwin M80-5401642 pin numbering

Pin allocations are as follows:

Pin	Name	Type	Description
1	TS3-	Input	Temperature sensor 3, negative input
2	TS2-	Input	Temperature sensor 2, negative input
3	TS1-	Input	Temperature sensor 1, negative input
4	Ground	Ground	
5	Ground	Ground	
6	Ground	Ground	
7	I_EXT-	Input	External current sense, negative input
8	CAN L	I/O	CAN data, low side
9	TS3+	Input	Temperature sensor 3, positive input
10	TS2+	Input	Temperature sensor 2, positive input
11	TS1+	Input	Temperature sensor 1, positive input
12	Master shutdown	Input	Active low master shutdown input
13	Analog voltage	Input	Analog voltage input
14	3.3VDC power	Output	Power source for external current sensor
15	I_EXT+	Input	External current sense, positive input
16	CAN H	I/O	CAN data, high side

Table 4 – Interface connector pin allocations

#### 7.4.1 CAN interface

The CAN interface is not terminated internally. The CAN protocol is described in detail in the CAN protocol document.

#### 7.4.2 Analog voltage

The analog voltage input is used to turn balancing on and off, if configured to do so. It may be driven by a logic-level signal if its switching threshold is configured appropriately.

#### 7.4.3 Master shutdown

Pull low to shut down the battery balancer. This input has an internal pull-up resistor, and so connection to this pin is optional.

#### 7.4.4 External temperature sensors

The battery balancer supports up to 3 external temperature sensors. Connection of temperature sensors is optional. The temperature sensor inputs are designed for 10k NTC thermistors. Devices with a beta of 3950K will give the most accurate results (typically within +/-1 degree from -20 to +65C), but any 10k NTC thermistors will work acceptably well.

Connect thermistors between TSx+ and TSx- pins. Although these pins are designated plus and minus, 10k NTC thermistors are not polarised and may be connected with either polarity.

The temperature sensor inputs are not referenced to ground; do not allow these connections to come into contact with any externally applied voltages or damage to the battery balancer may occur.

#### 7.4.5 External current sensor

An external current sensor with a differential voltage output may be connected across the I\_EXT+ and I\_EXT- pins. The 3.3VDC power output is provided to power this sensor. To conserve power the 3.3VDC power output is turned off whenever the battery balancer is asleep or shut down.

External current sensing may be used at the same time as internal current sensing. Measured currents are reported separately in the CAN data streams.

## 8 Configuration Software

The configuration utility is a Windows application that allows configurable settings to be read from and written to the Battery Balancer. Settings can also be saved to file and retrieved for later use. The file format is XML, and so Battery Balancer settings files can be inspected using any browser or text editor.

The configuration utility may be downloaded from [www.millswoodeng.com.au/resources.html](http://www.millswoodeng.com.au/resources.html)

To configure the Battery Balancer, simply connect it to a PC with a micro-USB cable and run the configuration utility. Be aware that some micro-USB cables intended for charging do not have the data lines connected. These cables do not work.

The Battery Balancer will power itself from the USB connection.

The main page of the configuration utility consists of tabbed pages, and there is a menu across the top. The "Connection" menu allows selection of the serial port to which the Battery Balancer is connected. Once connected successfully, the "Device" menu will become accessible. This menu allows reading and writing to the Battery Balancer, as well as viewing its serial number and upgrading its firmware.

### 8.1 Configure tab




Figure 5 – Configure tab

When written to the Battery Balancer, settings are stored in non-volatile memory and are retained after power is removed.

#### 8.1.1 Number of cells

Select the number of cells in the battery.

#### 8.1.2 Current sensor

Select the gain of the external current sensor.

#### 8.1.3 Wiring diagrams

Click on the diagram to display a larger version of the wiring diagram corresponding to the number of cells selected. Wiring diagrams are also given in section 12 of this document.



#### 8.1.4 Balancing control

Select one of the 5 control options:

- **Off:** Balancing is disabled.
- **On:** Balancing is enabled and occurs whenever:
  - the cell voltage spread (max – min) exceeds the cell balancing target, or
  - a cell's voltage exceeds the maximum permitted cell voltage.
- **On when battery voltage exceeds:** Balancing is enabled whenever the battery voltage is above the threshold specified.
- **On when analog voltage exceeds:** Balancing is enabled whenever the analog input voltage is above the threshold specified.
- **Integrated with GCU via CAN interface:** Balancing is enabled whenever the battery is being charged by the GCU. This is described in more detail in section 8.1.7 below.

If “**Allow sleep**” is checked, after 32 seconds of inactivity the Battery Balancer will go to sleep. It will wake every 32 seconds to re-measure the battery voltages and temperature and check for any CAN activity. If balancing needs to be performed the Battery Balancer will remain awake to do this, and then go back to sleep again afterwards.

When the Battery Balancer goes to sleep, the 2 LEDs will glow green very faintly. This is normal and does not draw any appreciable current.

The Battery Balancer will wake (and remain awake) if connected to a PC. It will also remain awake if CAN packets addressed to the Battery Balancer are present on the CAN bus.

The “**Time awake**” setting may need to be increased if waking due to CAN activity is required and CAN messages are infrequent.

#### 8.1.5 Cell voltage limits

- **Maximum cell voltage:** The maximum safe voltage for cells to be charged up to. Cells with voltage exceeding this limit will be discharged until they reach this limit.
- **Minimum cell voltage:** Cells will never be discharged below this voltage.
- **Balance cells to within:** The target cell voltage spread that the Battery Balancer will attempt to reach by discharging cells with higher voltages. There is 10mV of hysteresis, so that once the target is reached balancing will not resume until the spread between cells exceeds the target plus 10mV.

#### 8.1.6 CAN interface

- **Bit rate:** Select the same bit rate for all devices sharing the CAN bus.
- **CAN address of this device:** Choose a unique 16-bit address for the Battery Balancer. The Battery Balancer will respond to this address and also to the global address of 65535 (FFFF Hex).
- **Packet streaming:** Enables the regular transmission of measured data. Data may also be requested (polled) from the Battery Balancer.
- **Packet period:** Sets how often measured data is transmitted, if packet streaming is enabled.

The CAN protocol is described in detail in the CAN protocol document.

### 8.1.7 GCU integration

These settings are only relevant if the balancing control option selected is "Integrated with GCU via CAN interface". When this option is selected the balancer communicates with the GCU via CAN in order to manage balancing and charging.

- **Side of GCU battery is connected to:** In order to perform these tasks the balancer needs to know which side (A or B) of the GCU it is connected to, so that it can turn the appropriate charging circuit off and on.
- **CAN address of GCU:** The balancer also needs to know the CAN address of the GCU that is charging its battery, so that it can identify the data it needs and direct commands to the appropriate CAN device.
- **Only charge when T<sub>bat</sub> is between:** The balancer also needs to know the temperature range over which the battery may be charged and balanced. If no temperature sensor is fitted, the balancer recognises this and allows charging and balancing to occur regardless of the temperature.

The balancer inspects the data on the CAN bus to determine when battery charging is occurring, and requests this information periodically if it is not already present. No special configuration of the GCU is necessary. If communication with the GCU cannot be established or is lost, battery management halts until communication is re-established.

The balancer stops balancing and turns charging off if the battery is outside the specified temperature range. Charging is turned on again when the temperature returns to within the specified limits. To prevent excessive on/off cycling, 5 degrees of hysteresis is applied to the temperature limits.

If cell overvoltage occurs whilst charging, the balancer will halt charging and discharge the cell to a safe value before continuing. Charging may cycle on and off for this reason.

The balancer terminates charging when the battery is fully charged (average cell voltage within 50mV of the maximum permitted, corresponding to a state of charge of 95% for Lithium polymer batteries). The balancer restarts charging when the average cell voltage falls to below this level.

### 8.1.8 Visual indicators

- **Show fully balanced when cell voltages within:** This is the threshold for determining the colour of the balance LED. If the cell voltage spread is less than this threshold, the balance LED will be green.
- **Show fully charged when battery voltage exceeds:** This is the threshold for determining the colour of the charge LED. If the battery voltage is above this threshold, the charge LED will be green.

These thresholds apply only to the visual indicators; they do not affect operation of the Battery Balancer in any way.

***Note that with default configuration settings, the charge LED is only valid at zero current. When under any significant load the charge LED will be red, but this does not mean that the battery is flat.***

## 8.2 Voltages tab

The configuration utility is able to display a battery's cell voltages in real-time.




Figure 6 – Voltages tab

All of this data is also available via the CAN interface. The CAN protocol is described in detail in the CAN protocol document.

## 8.3 Current and Temperature tab

The configuration utility is able to display measured currents and temperatures in real-time.




Figure 7 – Current and Temperature tab

All of this data is also available via the CAN interface. The CAN protocol is described in detail in the CAN protocol document.

## 9 Specifications

### 9.1 Absolute Maximum Ratings

Stresses beyond those listed under Absolute Maximum Ratings may cause permanent damage to the device. These are stress ratings only, which do not imply functional operation of the device at these or any other conditions beyond those indicated under Recommended Operating Conditions. Exposure to absolute-maximum-rated conditions for extended periods may affect device reliability.

Symbol	Parameter	Min	Max	Unit
$V_{BAT}$	Battery voltage	-0.3	+100	$V_{DC}$
$V_{CELL}$	Cell voltage	-0.3	+9	$V_{DC}$
$V_{ANALOG}$	Analog input voltage range	-100	+100	$V_{DC}$
$I_{SENSE}$	Internal current sensor current	-100	+100	$A_{DC}$
$V_{ISENSE}$	Internal current sensor voltage range	-14	+80	$V_{DC}$
$V_{CAN\_L}$ , $V_{CAN\_H}$	CAN L and H voltage range	-58	+58	$V_{DC}$
$T_{INT}$	Internal temperature	-55	+105	$^{\circ}C$

Table 5 – Absolute Maximum Ratings

### 9.2 Recommended Operating Conditions

Symbol	Parameter	Min	Max	Unit
$V_{BAT}$	Battery voltage	18	65	$V_{PP}$
$V_{CELL}$	Cell voltage	2	5	$V_{DC}$
$I_{SENSE}$	Internal current sensor current	-80	+80	$A_{DC}$
$V_{ISENSE}$	Internal current sensor voltage range	-14	+80	$V_{DC}$
$I_{3V3}$	3.3VDC power output current		50	$mA_{DC}$
$V_{ANALOG}$	Analog input voltage range	0	50	$V_{DC}$
$V_{CAN\_L}$ , $V_{CAN\_H}$	CAN L and H voltage range	-12	+12	$V_{DC}$
$T_{INT}$	Internal temperature	-40	+85	$^{\circ}C$

Table 6 – Recommended Operating Conditions

### 9.3 Electrical Specifications

Minimum and maximum limits apply across the range of values given in the recommended operating conditions. Typical values are measured with  $T_{INT} = +25^{\circ}C$ .

	Min	Typ	Max	Unit
<b>Cell parameters</b>				
Discharge resistance		10		$\Omega$
Measurement accuracy ( $V_{CELL} = 3.6 - 4.3 V$ )	-40	$\pm 10$	+40	mV
Measurement accuracy ( $V_{CELL} = 3.2 - 4.6 V$ )	-40	$\pm 15$	+40	mV
Measurement accuracy ( $V_{CELL} = 2.0 - 5.0 V$ )	-50	$\pm 25$	+50	mV
Balancing hysteresis		+10		mV
<b>Internal current sensor</b>				
Measurement accuracy		$\pm 1$		A
Series resistance		250		$\mu\Omega$
<b>3.3VDC power output</b>				
Voltage (no load)	3.1	3.3	3.5	V
<b>Analog input</b>				
Measurement accuracy		$\pm 250$	$\pm 500$	mV
Input impedance	220			$k\Omega$
<b>Temperature (using 3950K 10k NTC)</b>				
Measurement accuracy (-20 to +65 $^{\circ}C$ )		$\pm 1$	$\pm 2$	$^{\circ}C$

Table 7 – Electrical Specifications

## 10 Document version history

### 10.1 0.9 -> 1.0


- Initial release.

### 10.2 1.0 -> 2.0

- Internal current sensor changed to bi-directional.
- Analog input voltage range increased (section 9).
- External power output voltage changed.
- Wiring diagrams updated to reflect new solderbridges (section 12).
- CAN common-mode voltage range updated (section 9).
- Mating connector part numbers added (section 7).

## 11 Reference data

### 11.1 Typical Lithium polymer characteristics at 23 °C



Graph 1 – LiPo cell voltage versus state of charge at 23 °C

With regard to Graph 1, the no load curve is the average of a large number of datasets. It is the only curve that applies to LiPo cells in general. The loaded curves vary significantly between batteries because manufacturers use different criteria to determine their C ratings.

## 12 Wiring diagrams

